

#1652 & #1653 BOTTLE STOPPER KITS



#1653

Instructions for #1652 & #1653 Bottle Stopper Kits

Using a 6mm drill bit, drill a hole in a piece of wood a bit longer than the length of the screw on the bottle stopper kit.

Screw the threaded end of the bottle stopper mandrel into this hole until the wood shoulders against the round stop collar.

Mount the shaft of the mandrel into your lathe using a chuck, drill chuck or any other chuck that allows you to clamp this threaded rod into the head stock of the lathe. Support the other end of the wood on the tail stock center, and turn the wood to the desired shape.

Unscrew the mandrel from the wood and then screw the wood onto the bottle stopper screw.

You may want to use glue to fix the wood on the stopper permanently. Use Epoxy (2 part) adhesive for permanence.

The mandrel can be a home made unit - simply get a bolt of the same size of the threaded end of the stopper, remove the head from the bolt and clamp it into your favorite chuck.



#1652